

SEWAGE SPILL CLEANUP: INTERIOR EMERGENCY PROCEDURE

APPLICATION

This procedure describes the steps for cleaning up an interior sewage spill at the Lab.

SPECIAL INSTRUCTIONS

- Due to the potential for biological hazards from spilled sewage, it is essential that this procedure be followed carefully and that personnel avoid contact with the spilled material.
- **Special Equipment:** Rubber gloves, eye protection and rubber boots.

WORK STEPS


1. Cordon off the affected area with yellow tape, barricades, or wet floor signs.
2. Clean up spill:
 - Use mop and bucket for liquid waste.
 - Use shovel or available dust pan for solid waste.
3. Dispose of sewage in nearest available toilet.
4. Wash all affected floors, walls, and furniture with a 10% bleach, 90% water solution.
5. Clean, disinfect, and rinse cleaning equipment from Step 3.
6. Disinfect, rinse, and dispose of expendable equipment (e.g., cloth rags, rubber gloves, boots).

REFERENCES

None.

RESPONSIBILITIES AND CONTROLS

Provide signature lines as follows:

Rev. No.	SME/Title	Approved/Title	Date	Effective Date
2	 Jim Murphy Maintenance Supervisor	 Ken Fletcher Operations Department Head	5-22-09	5-22-09